



SSJ mechanism instructions



1- Seat height adjustment

To lower the seat, stay seated and pull the lever up until the desired seat height is reached. To raise the seat, pull the lever while lifting your weight off the seat.

2- Seat depth adjustment

Pull the lever up, slide the seat forward or backward until the adequate position is reached and then release the lever.

3- Backrest angle adjustment

Bend forward to release pressure off the backrest. Pull the lever up, apply pressure with your back to position the backrest and release the lever.

4- Tilt lock

To allow the chair to tilt, pull the lever up. To lock the tilt option, push the lever down.

5- Tilt tension adjustment

To adjust the tilt tension to the user's weight and position on the chair, turn the knob clockwise to increase the tension and counter clockwise to decrease it.